

United States District Court

MIDDLE DISTRICT OF FLORIDA

Orlando Division

Document Camera Quick Reference



This unit is equipped with a high-resolution camera and features a 12x optical zoom lens and a high accuracy auto focusing system. The WolfVision VZ-8plus3 document camera presents all types of materials to view through monitors, e.g. 3-D objects, paper documents, transparencies, x-rays, etc.

Using the WolfVision Document Camera

Ask the courtroom deputy to select the document camera as the source of evidence.

Place the evidence on the work surface. While you observe the image, adjust the zoom to obtain the optimum size.

Fine-tune the image using the manual focus if necessary.

Lighting Option

You may activate the document camera lamp if additional light is needed.

Zoom

The zoom function lets you adjust the image size and zoom into a specific section. Turn the zoom wheel to the desired range.

